



EDIS USER GUIDE

EDIS Dash Board & User Permissions

(EDIS is the Electrical Distribution Information System)

www.electricalcertificates.co.uk



After reading this document you should be able to:

- Understand the EDIS Dash Board
- Understand EDIS User roles

Contents

After reading this document you should be able to:.....	2
1. Login and select an estate and building	3
USER PERMISSIONS	3
SECTION 1- Search Buildings	4
SECTION2 – Request Building permissions	4
SECTION 3 – Building details	4
SECTION 4- Current building permissions	4
SECTION 4 – Request new estate	5
Next steps.....	5



1. Login and select an estate and building

1. Enter the site www.electricalcertificates.co.uk and log in.

2. Choose the required Estate, from a list of available

3. Select a Building from the list below.

After selecting a building the dash board page is displayed

The screenshot shows the EDIS Dashboard interface. At the top, the navigation bar includes 'EDIS' logo, 'Estate 202' (highlighted with a red box), 'Build202/2' (highlighted with a red box), 'Building that has been selected' (text), and 'Contact System Admin'. Below the navigation bar, there are several sections:

- ESTATES:** Shows 'Estate 202' in a dropdown menu.
- BUILDINGS:** Contains search fields for 'Search Building Name', 'Search Building Reference', and 'Search Building Address'. A red box labeled '1.' highlights the 'Search Building Name' field. Below these are buttons for 'Search' and 'Clear Search'. A list of buildings is shown, with 'Build202/2' highlighted by a red box labeled '2.'. Other buildings listed include 'Build202/1', 'Build202/3', 'build202/4', 'build202/5', and 'Building 202'. Each building entry has four small buttons at the bottom: 'ES' (blue), 'CN' (green), 'DA' (grey), and 'DE' (red).
- Building Details:** Displays the selected building's information: 'Building Name: Build202/2', 'Address: Build202/1 a, Build20121 b, Build202/1 c, Build202/P', 'Number of Floors: 7', 'Building Area: 8.0', and 'Description of Premises: Commercial'.
- Building Administrators:** A table showing users assigned as administrators. It includes columns for 'User' and 'Email'. The table is highlighted with a red box labeled '3.'.

Building Administrators	
Edis user two o three	edisuser203@gmail.com
User 202	edisuser202@gmail.com
Edis User 201	edisuser201@gmail.com
- User Roles and Actions:** A section on the right with a red box labeled '4.' containing 'Current Roles: EA, EV, BA, ES, CN' and two buttons: 'Request Estate Visibility' and 'Register New Estate'.

Figure 1- EDIS Dashboard page

USER PERMISSIONS

SA	Systems Admin	Approves estate creation
EA	Estate Admin	Approves requests for BA permissions
BA	Building Admin	Creates and manages the buildings and approves building access requests
EV	Estate Visibility	Estate visibility is requested by a user; this allows the user to see, but not access building in the estate

ES	Electrical Supervisor	Authorises Condition Reports and New Installation certificates
CN	Contractor	Creates, edits and completes certificates, certifies certificates
DA	Data Administrator	Can capture board and certificate data, cannot complete certificates.
DE	Designer	Can certify New Installation certificates

SECTION 1- Search Buildings

If the estate has many buildings – the building search feature can reduce the number of buildings; this allows you to easily find the building you require.

If the building name is highlighted you have access to the building.

SECTION2 – Request Building permissions

The building selected is shown at the top of the browser page. If the building name is not highlighted then you do not have access to the building.

If you do not have building access you will need to request building access.



This is done by clicking on the icons next to the building; if you click the icon an email will be sent to the Building Administrator and they will approve your request:

ES	Electrical Supervisor	Authorises Condition Reports and New Installation certificates
CN	Contractor	Creates, edits and completes certificates, certifies certificates
DA	Data Administrator	Can capture board and certificate data, cannot complete certificates.
DE	Designer	Can certify New Installation certificates

SECTION 3 – Building details

The Middle section shows the building address and the building administrators; building administrators can be asked to provide building access and permissions.

SECTION 4- Current building permissions

After selecting a building from the building list - you will see the permissions you have on the top right hand side of the page.

If you do not have access to an estate, you can request estate visibility; an email will be sent to the building administrator and they will approve/deny the request.

SECTION 4 – Request new estate

If you require a new estate, you can request a new estate; an email will be sent to the System Administrator and they will approve/deny the request.

Next steps

Login at www.electricalcertificates.co.uk